

Management of organochlorine and related residues

Dan Byrne

Technical Specialist Residue Management,
Biological & Chemical Risk Management,
Tamworth

Management of persistent chemicals in soil is an important issue for modern-day graziers. It is one of the key points addressed by livestock industry quality assurance programs such as Livestock Production Assurance (LPA), LPA QA (including Cattlecare and Flockcare) and the National Feedlot Accreditation Scheme (NFAS).

For example, the LPA QA Code of Practice requires accredited producers to: identify any part of the property that may be contaminated by persistent chemicals; manage those areas to prevent stock being exposed to contamination; and identify and manage any stock that are exposed to contamination.

Organochlorine (OC) pesticides are the main concern of these industry programs as these chemicals can persist in the soil for decades. Aldrin, BHC, chlordane, DDT, dieldrin, HCB and heptachlor have all been found as residues in livestock.

The use of these OCs to control pests in crops such as potatoes, corn, cotton, lucerne, bananas and sugarcane has been progressively phased out over the past 20 years. Use of OCs for termite control ceased in July 1995. Chemicals from this group were used to control external parasites on sheep and cattle until 1962.

Organochlorines are not water-soluble. They bond strongly to soil particles and move only when the soil is displaced. OC levels in soil generally decline very slowly. Research suggests some OCs have a half-life in soil of more than 20 years.

The rate of breakdown depends on various factors including the chemical involved, climate and soil type. In many cases, sites of spillage, storage or disposal have proven to be a problem.

Stock readily pick up residues if they have access to localised areas of high level contamination or old chemical containers.

Stock also pick up OC residues when grazing previously treated land. Grazing animals take in variable amounts of soil as they feed and any OC residues in this soil accumulate in the animal's body fat. Factors such as pasture length, species, and density affect the amount of soil consumed.

Similarly, mud splash and dust on fodder increase soil uptake by livestock.

Polychlorinated biphenyls (PCBs) are another group of OC chemicals. These oily liquids were added to transformer oils and some hydraulic oils as a fire retardant. PCBs can be very persistent in soil and stock.

Most PCB residues in stock have come from direct access to old leaking electrical equipment, or from grazing areas where old PCB oils have been spilt.

Endosulfan is also a member of the OC group of pesticides but is not persistent in soils. The chemical is still registered for use in agriculture and horticulture. It can cause residues in stock fed waste from treated crops or exposed to feeds contaminated by spray drift.

The Australian Pesticides and Veterinary Medicines Authority (APVMA) has revised the registered uses for endosulfan over recent years. This chemical is no longer registered for use on pastures or on any fodder or forage crops. Pre-emergent use is allowed on some cereals, pulses and oilseeds.

Full details of the current registered uses for endosulfan are available on the APVMA's website at: www.apvma.gov.au/chemrev/endosulfan_user_brochure.pdf

Obtain professional advice before feeding or grazing stock on any endosulfan treated materials. Check the current label requirements *before* using endosulfan on any crop.



Maximum residue limits

Residue tolerance levels, which are called maximum residue limits (MRLs), are set for various chemicals in different commodities. MRLs are based on good agricultural practice and scientific evidence that the MRL does not represent a health risk to consumers.

MRLs are in place for OC chemicals because residues that are present in the environment as a result of their past use can cause residues in food. These MRLs are not intended to allow continuing use of these chemicals. There are now no legal uses for any of the persistent OC pesticides.

MRLs can vary between different commodities and from country to country. For example, the Australian MRL for dieldrin in beef fat is 0.20 mg/kg (1 part in 5 million) while the MRL for cereal grains is 0.02 mg/kg (1 part in 50 million).

By comparison, the United States has a slightly higher MRL for dieldrin in fat of meat (0.3 mg/kg). Similarly, Australia, Japan and the USA have a DDT MRL of 5 mg/kg, while the EU and Canada have 1 mg/kg.

Meat processors and government agencies carry out extensive residue monitoring on slaughter stock. Any carcass with a residue above the Australian MRL is condemned for human consumption. The producer receives no payment for condemned carcasses.

Fluctuations in cattle OC residue levels

OC residue levels in cattle change with time, depending on factors such as:

- residue intake rate;
- dilution or concentration due to changes in body weight; and
- loss through lactation.

For example, dieldrin levels in mature dry cattle are expected to halve every 3-4 months if there is no further exposure to the chemical and the cattle are maintaining or gaining body weight. In comparison, PCB residues break down very slowly. As a result, high PCB levels in fat mature cattle will not generally decline to below MRL.

Suckling calves can take up OC residues from their mother's milk. Residue levels in suckling calves sometimes reach up to five times those found in their dam's milk fat.

Lactation, however, helps reduce residue levels in cows as chemicals are removed from their body in the milk. Provided they are not exposed to further contamination, residues which suckling calves gain from their dam can fall rapidly as the calves grow and lay down body fat after weaning.

Property risk management process

Obtain a monitoring history

Since the mid-1970s, residue results from field and abattoir testing have been recorded against Property Identification Codes (PICs) on the NSW Department of Primary Industries chemical residue database. Reports of abattoir results recorded against your registered PIC can be obtained from the District Veterinarian (DV) at your local Rural Lands Protection Board.

The DV protects the confidentiality of the information by ensuring the report only lists results for the inquirer's registered PICs. In some situations, results of tests on cattle previously run on land which you now own or occupy may be available.

In most cases where OC residues above half the MRL are detected, a field investigation is done to determine the source of the residues and the management processes needed to control them.

In 1996 a new program called the National Organochlorine Residue Management (NORM) Program began, with funding from producer levies. It aims to reduce OC residues in beef through improved management of contaminated land and close monitoring of cattle from at-risk properties.

Assess the risk of OC residues

Participants in industry quality assurance programs are required to complete a comprehensive property risk assessment for persistent chemicals and to maintain a record of the assessment process.

This approach is strongly recommended for all properties producing livestock for human consumption and irrespective of past monitoring results.

Identified OC risk areas in NSW include:

- Land used for growing potatoes, corn, bananas, sugarcane, tobacco and lucerne before 1986.
- Land used for orchards before 1988 and vegetable production before 1986.
- Cotton growing areas before 1982 (DDT).
- Sheep dip sites used before 1963.
- Old containers or chemicals in farm rubbish dumps.
- Sheds containing old OC chemicals or OC-fortified fertilisers.
- Cattle tick dip sites in the north-eastern NSW cattle tick control area.
- Buildings, yards, fences, stumps, bridges, power poles treated with OC chemicals for termite control.

- Silos treated with OC chemicals for termite or weevil control.
- Old pickled seed grain treated with HCB to control bunt.
- Sites below leaking electrical transformers.
- Land treated with OC chemicals for Argentine ants in the Sydney area.
- Chemical storage, mixing and disposal sites.
- Lawn clippings from OC contaminated areas.

Identify any likely risk areas on your property. Gather all available information on past OC use, including information from previous owners.

Assess the potential for these sites to cause contamination of stock. Soil sampling may be required to determine if contamination is present and the level of any such contamination.

To discuss this, contact the NSW Department of Primary Industries Environmental Laboratories at Wollongbar on (02) 6626 1103 or the National Association of Testing Authorities (NATA) on (02) 9736 8222.

See also Primefact 320 *Testing soils for residues of persistent chemicals*

Manage contaminated sites

Obtain professional advice on managing risk sites. A properly documented property management plan records the problems identified and their solutions. District Veterinarians at Rural Lands Protection Boards and NSW Department of Primary Industries veterinary staff can help you to develop these plans.

Management strategies can include the following.

Exclusion – it may be possible to remove potential risks simply by fencing risk areas to exclude stock.

Removal – for small areas, excavate and replace with clean soil, with Department of Environment and Conservation (DEC) permission.

Grazing management – control and document grazing of risk areas to ensure that slaughter stock residues do not exceed residue standards.

In many cases, management plans will already be in place under the NORM program.

On-farm fat sampling of stock (a biopsy) may be necessary to ensure the effectiveness of the management plan, while avoiding the risk of carcasses being condemned at abattoirs. It is the producer's responsibility to ensure that all stock offered for sale meet market standards.

Failure to do so may leave the vendor liable to legal action.

Unwanted persistent chemicals

All use of persistent OC chemicals is banned in Australia. Old stocks of OC chemicals were disposed of during the NSW Agriculture (now NSW DPI) amnesty collections in 1987–88 or, more recently, through the Commonwealth and State Government ChemCollect program. Any remaining unwanted chemicals should be stored securely until permanent disposal can be arranged. Storage areas must be securely fenced to prevent stock access.

Old chemicals should be placed in a secure, leak-proof container, which will not corrode or decay and is properly labelled. Contact the DEC Information Line on 131 555 for further information on the disposal of waste chemicals.

Producers are warned not to dispose of unwanted chemicals except in accordance with DEC directions.

Feedlot and feeding sites

Take particular care with any site where stock are being held or fed. Ensure it was not an old sheep or cattle dip site or the site of previous OC treatments. If in doubt, have the soil tested. Livestock confined in feedlots or fed in yards or off the ground are very likely to pick up residues if the site is contaminated with OCs.

The Cattlecare and NFAS Codes of Practice provide for extra measures, such as soil tests or fat testing of cattle, to confirm that feedlot sites are not contaminated by persistent chemicals.

Other OC residue sources

Purchased stock food

Although uncommon these days, there have been serious past problems with OC-contaminated stock food. Contamination usually occurred in grains or hay that were stored in OC treated silos or sheds. The OC chemicals slowly vaporise and are absorbed into the feed. This can occur many years after an OC treatment.

Fodders harvested from OC contaminated land may also contain unacceptable OC residues if significant amounts of soil get into the cut feed. It is essential to minimise the pickup of soil when cutting fodder crops grown on OC contaminated land. This can be done by raising the cutting height and, wherever possible, harvesting the material directly, rather than raking and baling. Problems have arisen with fodders such as cane tops and forage sorghum cut from OC contaminated land.

Grain grown on OC contaminated land should not contain any significant OC residues unless it is unusually contaminated by soil.

Is there a problem?	Find out from	Action
Have OC residues ever been found in stock from your property?	RLPB District Veterinarians. Previous owners.	Get the best history possible and keep accurate records.
Were OCs used on your property for agricultural crops such as potatoes, lucerne, maize, sugarcane, bananas, orchards, market gardens, cotton or tobacco?	Previous owners. Neighbours. Soil tests.	Property management plans to: <ul style="list-style-type: none"> • Prevent or restrict grazing on contaminated land. • Reduce contaminated soil intake by stock from short or muddy pasture, or hand-feeding off the ground.
Were OCs used on your property: in sheep or cattle dips; to treat yards, fences or buildings; or to treat silos, feed storages or seed grain?	Previous owners. Neighbours. Soil and surface tests.	<ul style="list-style-type: none"> • Exclude stock or remove contaminated soil/timber to secure storage. • Keep feeds out of OC-treated storages. • Never feed pickled seed grain to stock.
Were OCs ever used on your property to treat power poles for white ants, or have PCBs leaked from electricity transformers, electric motors or hydraulic equipment?	Electricity supply authorities. Previous owners. Soil tests.	Identify any OC hot spots, exclude stock or remove contaminated soil/timber to secure storage.
Was your land ever treated for Argentine ant infestation (applies mostly in the County of Cumberland)?	RLPB District Veterinarians. Previous owners. Neighbours. Soil tests.	Exclude stock from treated areas.
Is there any contamination from poor on-farm disposal of old chemicals and 'empty' drums; or spillage at chemical storage, loading, or wash-down sites?	Inspection of rubbish dumps and sheds. Previous owners. Soil tests.	<ul style="list-style-type: none"> • Exclude stock from rubbish dumps, farm sheds, chemical storage and mixing areas. • Remove or cover contamination.

Obtain Department of Environment and Conservation advice before attempting clean-up of contaminated areas or disposing of unwanted chemicals. Phone the DEC Information Line on 131 555. The line is STD toll free and staffed from 8.30 am to 5 pm, Monday to Friday.

Purchasers of stockfoods should seek vendor declarations regarding the OC residue status of land from which fodders have been cut. Also, ask about the stock food's chemical treatments and exposure to spray drift. If indicated, appropriate residue tests should be done before using the feeds. Particular care must be taken with materials which are not produced primarily for use as stockfeed.

Purchased Stock

OC residues can persist in cattle for a long time. Buyers should always require vendor declarations covering possible OC exposure of purchased stock, especially during the previous six months. Vendors should always supply an accurately completed National Vendor Declaration (NVD) when selling cattle.

© State of New South Wales
through NSW Department of Primary Industries 2007

ISSN 1832-6668

Replaces Agnote DAI-29

Check for updates of this Primefact at:
www.dpi.nsw.gov.au/primefacts

Disclaimer: The information contained in this publication is based on knowledge and understanding at the time of writing (January 2007). However, because of advances in knowledge, users are reminded of the need to ensure that information upon which they rely is up to date and to check currency of the information with the appropriate officer of New South Wales Department of Primary Industries or the user's independent adviser.

Job number 7100