

Estimating tractor power needs

April 2021, Primefact DOC21/78404, First edition. Adapted from NSW Farmers factsheet
<https://www.aginnovators.org.au/initiatives/energy/information-papers/estimating-tractor-power-needs>

Liz Hutton & John O'Connor, Climate Branch, NSW DPI - Agriculture

This factsheet provides guidance and calculation tools to enable you to determine the appropriate power and size of tractor that your field operations will require. This is of critical importance, as a machine that's not well matched for the tasks it will perform is likely to operate inefficiently. This can lead to fuel waste or early breakdown.

Introduction

Tractors throughout Australia tend to be over-powered for the tasks they perform. This is likely because the most common approach farmers acquiring tractors have taken to date has been to opt for those with the highest 'horsepower per dollar' they can afford. This may be a false economy, since smaller tractors may be as capable of handling the major tasks farmers require, and save considerable amounts of fuel, so getting a good estimate of power needs is valuable. There are several methods to make this estimate:

- Use typical Rules of Thumb
- Use an Excel calculator to input your specific situations parameters,

- Calculate your parameters manually.

The following guidelines present methods by which you can determine the power requirements of your farm's specific field operations. Nonetheless, it is imperative that you obtain additional advice from experts and local industry leaders so you can adapt the method to your specific needs and situation.

"Rule of Thumb"

Typically, the required engine power per meter width of tillage implement will be around 20-35 kW, depending on the soil properties, cutting depth and speed of operations. In a light sandy soil, less power is required than for a heavier soil type. Faster speeds and deeper depth of operations will need more power so will be at the higher end of this rule of thumb estimate.

Manually calculate requirements

For those who love maths or developing things from first principles, the following information guides you through the process:

Step 1: Identify your 'priority critical field operation'

List all the tasks you'll need the new machine to perform, such as: fertiliser/chemical application, tillage, loader work, PTO-driven operations, etc. Consider that an occasional high-horsepower task may not justify dragging extra tonnage around on a daily basis. It may be more cost-effective and fuel efficient to subcontract out such tasks.

Review the list of tasks that the machine will perform and **identify the most critical operation that will require an implement with the highest draft force.** (Draft is a measure of the **pull** force imposed by the implement on the machine as it travels through the soil.) Use Table 1 to help estimate the draft force from various implements.

Table 1: Draft and power requirements for tillage and seeding implements¹

Implement	Unit	Speed km/h	Draft force for soil type (N/unit/cm depth)		
			Clay	Loamy	Sandy
Major tillage tools					
Subsoiler/manure injector					
Narrow point	tools	8	517	361	233
12-inch winged point	tools	8	669	468	301
Moldboard plough	metre	7	1,281	896	580
Chisel plough					
2-inch straight point	tools	8	201	172	131
3-inch shovel/14-inch sweep	tools	9	243	207	159
4-inch twisted shovel	tools	9	280	238	182
Sweep plough					
Primary tillage	metre	8	781	666	511
Secondary tillage	metre	8	517	437	333
Disk harrow, tandem					
Primary tillage	metre	9	672	592	529
Secondary tillage	metre	9	408	356	316
Disk harrow, offset					
Primary tillage	metre	8	770	672	598
Secondary tillage	metre	8	471	414	368
Disk gang, single					
Primary tillage	metre	9	224	195	172
Secondary tillage	metre	9	155	132	121
Coulters					
Smooth or ripple	tools	8	95	84	74

Bubble or flute	tools	8	114	100	89
Field cultivator					
Primary tillage	tools	8	88	75	58
Secondary tillage	tools	8	61	53	40
Row crop cultivator					
S-tine	rows	8	226	191	147
C-shank	rows	8	419	356	271
No-till	rows	8	730	620	475
Rod weeder	metre	7	362	310	236
Disk-bedder	rows	8	366	315	285
Minor tillage tools					
Rotary hoe	metre	11	305	305	305
Coil tine harrow	metre	8	115	115	115
Spike tooth harrow	metre	8	299	299	299
Spring tooth harrow	metre	8	1,046	1,046	1,046
Roller packer	metre	8	345	345	345
Roller harrow	metre	8	1,551	1,551	1,551
Land plane	metre	8	4,585	4,585	4,585
Seeding implements					
Row crop planter, prepared seedbed					
Mounted – seeding only	rows	8	242	242	242
Drawn – seeding only	rows	8	438	438	438
Drawn – seed, fertiliser, herbicides	rows	8	767	767	767
Row crop planter, no-till					
Seed, fertiliser, herbicides – 1 fluted coulter/row	rows	8	898	898	898
Row crop planter, zone-till					
Seed, fertiliser, herbicides – 3 fluted coulter/row	rows	8	1,809	1,809	1,809
Grain drill w/press wheels					
< 6.5 feet drill width	rows	8	198	198	198
6.5 to 10 feet drill width	rows	8	147	147	147
> 10 feet drill width	rows	8	54	54	54
Grain drill, no-till					
1 fluted coulter/row	rows	8	378	378	378
Hoe drill					
Primary tillage	metre	8	3,620	3,620	3,620
Secondary tillage	metre	8	1,724	1,724	1,724
Pneumatic drill	metre	10	2,155	2,155	2,155

Step 2: Estimate the time you'll have available to complete this priority task

Determine the time period available to complete your priority critical field operation. As an illustration, your requirements may be for tillage work to be completed over the span of a week, working Monday through Friday, eight hours a day. This equates to having 40 hours available for the job.

¹ Tables 1&2 adapted from Williams, P. E. S. a. E. J., 2007. *What Size Farm Tractor Do I Need?*

Step 3: Find the work rate (hectares per hour)

Once you have determined the time available, you can calculate the required hectares-per-hour (ha/h) rate using your farm's dimensions. Continuing from our previous example, assume that the size of the field for tillage is 120 hectares. This means that the task must operate at the following rate:

$$\frac{120 \text{ ha}}{40 \text{ h}} = 3 \text{ ha/h}$$

Step 4: Determine the width of the implement required

The next step is to use the work rate of your operation (i.e. how many hectares you need to cover per hour) and the expected working speed of the job to determine the width of the implement required. This is given by the following equation:

$$\text{Required implement width} = \frac{11.8 \times \text{work rate (ha/h)}}{\text{working speed (km/h)}}$$

The 'work factor' 11.8 is a dimensionless number that represents the number of hours required to cover an entire hectare when using a metre-wide implement, at 1 km/hr, assuming losses of 18 percent from overlapping, turning and other field inefficiencies. Following from the previous example, let's establish that we'll be using an offset disc harrow to conduct primary tillage at 8 km/h. The required width of the offset disc plough can therefore be determined as follows:

$$\begin{aligned} \text{Required implement width} &= \frac{11.8 \times 3 \text{ ha/h}}{8 \text{ km/h}} \\ &= 4.425 \text{ m} \end{aligned}$$

Alternatively...

If you already know the size of the implement that will be used with your machine, you may wish to determine the work rate your equipment will allow for. You may do this using the following equation:

$$\begin{aligned} \text{Work rate (ha/h)} \\ &= \frac{\text{implement width (m)} \times \text{working speed (km/h)}}{11.8} \end{aligned}$$

If the resulting work rate is too low for your requirements, consider obtaining a wider implement.

Step 5: Determine soil resistance

When conducting your priority field operation, identify the type of soil your field will have (i.e. clay, loamy or sandy). Use this information and Table 1 to find the resistance that will be offered by the soil per unit of width and depth (i.e. its draft force). Then calculate your total soil resistance by multiplying this measure by your expected working depth and the full length of the implement.

$$\text{Soil resistance} = \text{implement width} \times \text{working depth} \times \text{resistance per width}$$

Expanding from our previous example, let's assume that the soil type is sandy, that our offset disc harrow is for primary tillage and that the working depth is 10 centimetres. Table 1 tells us that this implement for this soil type will present a draft force of 598 Newtons per metre of implement width, per centimetre of depth. Hence, for our total width of 4.425 metres and the 10-centimetre working depth, we have:

$$\begin{aligned} \text{Soil resistance} &= 4.425 \text{ m} \times 10 \text{ cm} \times 598 \text{ Nm}^{-1} \text{ cm}^{-1} \\ \text{Soil resistance} &= 26,461.5 \text{ N} \end{aligned}$$

Step 6: Determine power required at the drawbar

Our next step is to equate this pulling force into the power required at the drawbar from the machine. Drawbar power is the power required to pull or move the implement at a given speed. This is obtained by using the following equation:

$$\text{Required drawbar power} = \frac{\text{soil resistance (Newtons)} \times \text{working speed (km/h)}}{3,600}$$

The number 3,600 is a required conversion factor that must be used if the working speed is provided in km/hour.

Alternatively, the equation can be simplified if the working speed is known in metres per second, as so:

$$\text{Required drawbar power} = \text{soil resistance (Newtons)} \times \text{working speed (m/sec)}$$

Following, once more, from our previous example, we determine that the drawbar power required is:

$$\text{Required drawbar power} = \frac{26,461.5 \text{ N} \times 8 \text{ km/h}}{3,600} = 58.803 \text{ kW}$$

Note that the drawbar power is typically only 60-70% of engine power, as shown below. The rest is used for overcoming the losses of tyre rolling resistance etc.

Step 7: Determine the PTO power required

The final step is to determine the power that your machine should have at the power-take-off point (PTO) so that it can achieve the required power at the drawbar. This is calculated using a rule-of-thumb multiplying factor, which takes into account the type of soil condition you will experience. These multiplying factors are shown in Table 2 below.

Table 2: PTO power multiplication factors for different soil conditions

Soil condition	Multiply drawbar kW by
Firm, untilled soil	1.5
Previously tilled soil	1.8
Soft or sandy soil	2.1

$$\begin{aligned} \text{Required PTO power} \\ &= \text{required drawbar power} \\ &\times \text{multiplying factor} \end{aligned}$$

For our running example, we will assume that conditions are for untilled soil. This means that our final PTO power requirement is given by:

$$\begin{aligned} \text{Required PTO power} &= 58.803 \text{ kW} \times 1.5 \\ &= 88.205 \text{ kW (118.28 hp)} \end{aligned}$$

Step 8: Adjust for further considerations

Before finalising your goal power, consider the following:

- The outcome produced by the previous steps is representative of the **minimum** power requirements for the set conditions that were inputted into the calculations. Different soil conditions, inefficiencies and various other set-up variables (hydraulics, driving methods, etc.) will play a role, and can substantially influence the real power that will be available and that will be required for a given task.
- To operate correctly, certain implements may require minimum PTO power and engine speeds. Consult your implement's specifications to identify such cases.
- Continuously using a machine that is underpowered for the tasks it

undertakes will damage it and decrease its lifespan.

- When taking advice or considering power requirements, it's important to remember that most engines are at their most fuel-efficient when working at 80 percent of their rated 'max' power output. Operation at or around 80 percent of full power will provide both optimal fuel efficiency and the promotion of a long, productive service life. Likewise, running an engine at light loads (30–50% of rated capacity) may not be the most fuel-efficient method for completing the task. Consider using a lower-powered tractor where possible.

Given this, we suggest that you increase the goal power calculated in the previous steps by 10 to 15 percent.

PTO versus engine power

Be careful with power metrics as they may be expressed differently for different machines! For 2WD and MFWD tractors, rated power is usually stated at the power take-off (PTO). For 4WD tractors, however, rated power is typically quoted at the engine (engine power). PTO power is approximately equal to 85 percent of engine power, due to various gear transmission friction.

Acknowledgements

This work has been produced by the NSW Primary Industries Climate Change Research Strategy funded by the NSW Climate Change Fund and reviewed by Prof Craig Baille and A/Prof Guangnan Chen from the *Centre for Agricultural Engineering* at the *University of Southern*

Queensland. It is adapted from the NSW Farmers factsheet developed under Farm Energy Innovation program that can be found at:

<https://www.aginnovators.org.au/initiatives/energy/information-papers/estimating-tractor-power-needs>

Please see this factsheet for more detailed information about this topic.

Reference number DOC21/78404

© State of New South Wales through Regional NSW 2021. The information contained in this publication is based on knowledge and understanding at the time of writing (December 2021). However, because of advances in knowledge, users are reminded of the need to ensure that the information upon which they rely is up to date and to check the currency of the information with the appropriate officer of the Department of Regional NSW or the user's independent adviser.